

Forensic Toolkit Imager (FTK Imager): Enhancing Evidence Preservation and Analysis

Forensic Toolkit Imager, developed by AccessData, stands out as a robust open-source software integral to digital forensics. Its primary function revolves around the creation of precise copies of original evidence, ensuring data integrity while facilitating efficient preservation and subsequent analysis.

One of the key strengths of FTK Imager lies in its ability to generate accurate replicas of the original evidence. This process occurs without introducing any alterations to the source, maintaining the *integrity* of the evidence throughout. By preserving the image of the original evidence, FTK Imager provides a stable foundation for copying data at an accelerated rate.

Speed is of the essence in digital forensics, and FTK Imager addresses this need by enabling swift data duplication. This feature not only expedites the forensic process but also ensures that the acquired data retains its integrity. The quick and accurate copying capability enhances the overall efficiency of forensic investigations.

FTK Imager incorporates an inbuilt integrity checking function, elevating its utility in the realm of digital forensics. This function plays a crucial role in ensuring the trustworthiness of the acquired data. By generating a hash report, FTK Imager facilitates the comparison of hash values between the original evidence and the created image. This step is instrumental in validating the


integrity of the forensic process and detecting any potential tampering or corruption.

In essence, FTK Imager emerges as a multifaceted tool that not only expedites the copying of data but also prioritizes the preservation and integrity of digital evidence. Its integration of an integrity checking function aligns with best practices in digital forensics, providing forensic investigators with a reliable and comprehensive solution for their analytical needs.

In the AlienImager lab, FTK Imager was used for a limited amount of analysis on an already created image, emphasizing its primary role as a tool dedicated to the creation of forensic duplicates.

Creating a forensic image is a pivotal phase in digital forensic investigations. This process involves generating a backup copy of the entire storage device, capturing all the essential information required for booting into the operating system. However, it's crucial to note that the imaged disk necessitates application to the hard drive for functionality. Merely placing the disk image files on a hard drive does not suffice for restoration; they need to be accessed and installed on the drive using a specialized imaging program. Furthermore, a single hard drive has the capacity to store numerous disk images, and these images can also find a home on flash drives with greater storage capabilities.

Upon installation, open the FTK Imager tool developed by AccessData. The initial window that appears serves as the tool's starting point. *Please note that FTK Imager 4.7.1.2 is used, there might be variations in other releases.*




Create a Disk Image/Forensic Duplicate




Now, you have the flexibility to select the source according to the drive at your disposal. This can either be a physical or a logical drive, contingent upon the nature of your evidence.


A physical drive constitutes the core storage hardware or component within a device, responsible for storing, retrieving, and organizing data.



A Logical Drive typically refers to a drive space formed on a physical hard disk. It possesses its own set of parameters and functions, operating independently within the system.




Specify the destination path for the upcoming image creation. From a forensic standpoint, it is advisable to duplicate it onto a distinct storage device, generating multiple copies of the original evidence to safeguard against any potential loss.




Choose the desired image format for the creation process. Several formats are available, each with its characteristics:

1. Raw (dd): This format involves a bit-by-bit replication of the original evidence, retaining an exact copy without any modifications. Raw images lack metadata.
2. SMART: Initially utilized for Linux, SMART is now less commonly employed.
3. E01: EnCase Evidence File, denoted as E01, is a widely used format for imaging and shares similarities with other forensic formats.

4. AFF: An abbreviation for Advanced Forensic Format, AFF is an open-source format type designed for forensic purposes.



After selecting the desired image format (dd in this lab), provide the necessary details for the image creation process to proceed. This includes specifying the destination path where the image will be saved and choosing an appropriate file name. Additionally, consider adding relevant case or evidence information to the image details for proper documentation and organization within the forensic investigation.




The image shows a software dialog box titled "Evidence Item Information" with a close button (X) in the top right corner. The dialog contains five labeled text input fields: "Case Number:" with the value "007", "Evidence Number:" with the value "123456", "Unique Description:" with the value "LabImager", "Examiner:" with the value "Michael Hegarty", and "Notes:" with the value "Same tool you can often use for Data Recovery". At the bottom of the dialog, there are four buttons: "< Back", "Next >" (which is highlighted with a blue border), "Cancel", and "Help". A large, light gray watermark with the text "Michael Hegarty" is oriented diagonally across the right side of the image.



Case Number:	007
Evidence Number:	123456
Unique Description:	LabImager
Examiner:	Michael Hegarty
Notes:	Same tool you can often use for Data Recovery

< Back Next > Cancel Help

After selecting the desired image format, provide the destination path for the image file, assign a suitable name to the image, and then proceed by clicking on the "Finish" button. Ensuring that the destination is on a separate and secure storage medium is crucial from a forensic standpoint. This practice helps maintain the integrity of the original evidence and creating multiple copies of the image further safeguards against any potential loss of critical data.



Please note that, the Image Destination must be at least the same capacity/size as the Image Source you are duplicating. The Duplicate can also be segmented.



The time it takes to create depends on the size of the storage space and the processing power of your machine. Advice, if you are duplicating your full storage space have a cup of tea.....

Once the image creation process is completed, FTK Imager automatically generates a hash result to validate the integrity of the forensic image. This hash result includes checks for MD5 Hash and SHA Hash, ensuring that the created image matches the original evidence bit-for-bit (More on MD5 and SHA in lectures and labs)

Additionally, the hash report identifies the presence of any bad sectors, providing a comprehensive verification of the image's accuracy and reliability. This step is fundamental in digital forensics to guarantee the authenticity and unaltered nature of the collected evidence.